

DO NOT RETURN TO RETAILER!

Quick Start Steps


1. INFLATE TIRES WITH AIR

Fill Both Tires to 50 PSI before riding



2. CHARGE BATTERY

Plug in charger wall cord. Wait for green light. Align and insert charging plug into bike. Light turns red while charging.



3. SELECT HIGH / LOW SPEED SETTING

Rocker switch is located behind hole in battery cover
Using a small tool or tooth pick, toggle towards the back for fast, and forward for slow. (Bike ships in slow setting)



BURROMAX.COM

3080 Elm Point Industrial Dr
St. Charles, MO 63301
800-742-1189

SEE USER MANUAL FOR
MORE DETAILED INSTRUCTIONS

NEED HELP? CALL 800-742-1189
Or Email info@burromax.com